

GEZA SQUARE GLASS SHOWER 1000X1000MM

- Place tray in position on floor and drill 50mm hole in side of tray or floor for waste outlet. Connect appropriate length 50mm pvc waste pipe to trap. Note: Do not connect 50mm pvc waste pipe to waste stack until shower is fully assembled and positioned



- Connect the 6 frame pieces together by using the 27mm screws.
- Firstly, connect one long frame to 2x smaller frame pieces in the 2 holes provided.
- Add the joining corner pieces to the smaller frame pieces using 1x of the shortest screws.
- Follow the same steps to connect the other longer frame with the 2x smaller frame pieces.
- Then join the frame together.




- Place the frame onto the tray and then add the back panel
- Connect the back panel to the frame using 4x 17mm screws in the holes provided down each side at the back of the panels where they meet the frame. Drill pilot holes if necessary
- Then add second back panel and join to the frame the same way.
- Connect the back panels together with another 4 screws.



- Use the thick 27mm screws and nuts to fix the back panels onto the tray in the holes provided. Use a drill to make a pilot hole in the tray.



- Fix one of the clear rubber strips to the long side of the clear glass panel which does not have holes in it for wheels.
- Cut off excess strip and push glass into the frame.
- Do the same steps for the other clear glass panel which has no holes for wheels.
- Screw in small silver stoppers in the top and bottom frames at the end of the glass panels.



- Add the double wheels into the holes at the top of the clear glass door sliding panel.
- Add the single wheels, which have springs, to the bottom of the sliding door panel.
- First place double wheels into the channel on the inside of the top frame.
- Clip the bottom wheels into the channel on the inside of the bottom frame by pressing on the springs to extend the wheels to secure them into place.



- **Add magnetic strips to the door and clear side panel where the two meet.**
- **The rubber strip with the big lip is for the other end of the sliding door panel - to close the gap between the fixed piece of glass and the sliding glass.**
- **If magnetic strips do not meet, remove the grey stoppers that are stopping the door on the inside of the top and bottom frames. Then drill new holes in the desired position and re fit the stoppers.**
- **Hang the harness with mixer, rose and arm over the back panel.**
- **Use silicon to secure the harness to the glass back panel.**
- **Use a good quality clear silicon along the inside edge of the shower at the base of the tray.**
- **Silicon other joints where necessary.**